


High Density Male DB 15 Connector,
Norcomp 180-015-102-001



DB 9 Backshell Kit,
Northern Technology C8800218



Belden 9541 cable or equivalent.
Length will be in 100' increments.

Viewed facing into
back of connector

Conxall 18 pin female connector,
13282-18SG-331




Viewed facing into
front of connector

Cable Connection Color Code

Pin 1	Brown
Pin 2	Orange/Black
Pin 3	Black
Pin 4	Blue
Pin 5	Tan
Pin 6	Pink
Pin 7	White
Pin 8	Red
Pin 9	Green
Pin 10	Orange
Pin 11	Violet
Pin 12	Yellow
Pin 13	White/Black
Pin 14	Gray
Pin 15	White/Red

NOTE:
Both connectors use same color code hookup.

Cable Part Numbers.
6' - Cirronet P/N CBLAP6
100' - Cirronet P/N CBLAP100
200' - Cirronet P/N CBLAP200
300' - Cirronet P/N CBLAP300
400' - Cirronet P/N CBLAP400
500' - Cirronet P/N CBLAP500




Title

WaveBolt AP-15 Cable Assembly Drawing

SIZE	FSCM NO.	DWG NO.	REV
A		800398	B
SCALE	SHEET 3 of 3		
	16 Jan 2003		

Attaching the Data/Power Cable Connector

The figure below shows the pin numbering of the Data/Power connector. The view provided is looking into the side of the connector into which the pins will be inserted.



The cable pins are installed by choosing the appropriate conductor color and connector hole location and inserting the pin into the hole until it “clicks” into place. Verify the pin is locked into place by gently pulling on the conductor.


If a pin is installed in the wrong connector location, use the extractor tool to remove the pin. Insert the extractor tool into the connector hole such that the tool surrounds the pin. Gently push the extractor tool completely into the hole. Remove the pin by gently pulling on the conductor. If the pin does not come out easily, it is an indication the tool is not fully inserted. Do not pull on the conductor forcefully as that can pull the conductor out of the pin.

Use the following color code to insert the pins into the connector:

CONNECTOR PIN	CONDUCTOR COLOR	CONNECTOR PIN	CONDUCTOR COLOR
1	Brown	9	Green
2	Orange/Black	10	Orange
3	Black	11	Violet
4	Blue	12	Yellow
5	Tan	13	White/Black
6	Pink	14	Grey
7	White	15	White/Red
8	Red		

Care must be taken to follow the color code correctly. An incorrectly assembled connector can damage the WBAPR or the WBAP Card or both.

Complete the assembly by placing the connector in the slot in one of the shell halves. Install the two retaining screws on both sides of the shell and through the holes on both sides of the connector, place the other shell half over the connector so the connector lies in the shell slot. Secure the connector shell halves with the nuts and bolts provided. Refer to the figures below.



3, ~~30~~
50

SINGLE-ENDED CABLES