

# Asynchronous Serial Interface TPU Function (UART)

By Josef Fuchs and Charles Melear

## 1 Functional Overview

The UART function uses two TPU channels to provide a 3-wire (RxD, TxD and GND) asynchronous serial interface. All standard baud rates and parity checking can be selected. The CPU interface to UART consists of a command register, which defines the operation (number of data bits, baud rate, parity); a status register, which gives information about the data register (empty or full) and errors (framing and parity); and a data register, which holds the data to be transmitted or data that has been received. These registers are implemented for the UART function using the TPU parameter RAM and host sequence bits.

## 2 Detailed Description

The UART consists of a transmitter, which can transmit serial data via a transmit data (TxD) pin, and a receiver, which can receive serial data via a receive data (RxD) pin. Both transmitter and receiver contain a single shift register that performs parallel-to-serial and serial-to-parallel conversion. Although a UART chip normally contains both the transmitter and receiver, implementing a full-duplex UART with the TPU requires independent receiver and transmitter channels, because each TPU channel controls only one pin (a channel can be either a transmitter or a receiver, but not both at the same time). While at least two TPU channels must be used for a fully-functional UART, it is not necessary to use both sub-functions together, nor to use the same number of receivers and transmitters. For example, the TPU could handle 13 transmitters and 3 receivers. There is also no restriction on which channels must be used to receive and transmit — any channel can be used to transmit data and any other channel can be used to receive data. Since baud rate for each channel is specified independently, a transmitter can have a different rate than a receiver.

The UART protocol allows selection of a parity bit to detect simple transmission errors. Parity can be generated and checked in three different ways: odd, even and no parity. All parity-types are supported with the UART function.

The UART protocol is not fixed to a specific number of bits for one data word. Although 8-bit words are normally used, some applications use 7-bit or 9-bit words. The UART function can use word lengths from one to 14 bits. Maximum data size is determined by the structure of the receive data register. The receive data register also has two error flags built into it (FE and PE, bits 14 and 15) to simplify consistent reads of both data and flags. The number of transmitter stop bits is fixed at one. The receiver can also handle fractional stop bits correctly, but the transmitter cannot generate fractional stop bits.

The UART function is double buffered. Both transmitter and receiver contain a shift register as well as a data register. The host CPU can write new data to the transmit data register while data is being transmitted, and can read data from the receive data register while data is being received.

The UART function can do back-to-back transfers. If data is available in time, the transmitter does not generate an idle line signal, but transmits exactly one stop bit followed by the start bit for the next data. An idle line condition only occurs if the transmit data register is empty after transferring data. The length of a transmit idle line condition is always divisible by the MATCH\_RATE parameter. The receiver can handle any length of idle line.



# Freescale Semiconductor, Inc.

Every data word begins with one start bit, which is always a logic zero. Following the start bit, a specified number of data bits are transmitted least significant bit first, then a parity bit is generated and transmitted if parity is enabled. The end of the data word is marked by one stop bit, which is always a logic one. An idle line consists of successive stop bits, which means that the line is at logic level one while idle. For example the ASCII character "A" is always transmitted as %0100000101.

This note uses the term "bit time" to refer to the time required to transmit or receive one bit. Bit time is determined by baud rate, using the formula:

$$\text{Bit Time} = \frac{1}{\text{Baud Rate}}$$

The receiver detects a data word by sensing the falling edge of the start bit. Since the UART function always treats the first falling edge after the initialization service request as a valid start bit, a receiver must be enabled only when the line is idle. A received bit is sampled only once, approximately halfway through the bit time.

## 3 Function Code Size

Total TPU function code size determines what combination of functions can fit into a given ROM or emulation memory microcode space. UART function code size is:

$$59 \mu \text{ instructions} + 16 \text{ entries (8 long words)} = \mathbf{67 \text{ long words}}$$

## 4 Function Parameters

This section provides detailed descriptions of function parameters stored in channel parameter RAM. **Figure 1** shows TPU parameter RAM address mapping. **Figure 2** shows the parameter RAM assignment used by the UART function. In the diagrams,  $Y = M111$ , where M is the value of the module mapping bit (MM) in the system integration module configuration register ( $Y = \$7$  or  $\$F$ ).


Except for the transmitter TDRE status bit and the receiver PE and FE error flags, parameters have the same meaning for both the receiver and transmitter sub functions. In general, every TPU parameter must be accessed as a 16-bit value. Do not access any parameter as a byte value. Refer to the *TPU Reference Manual* (TPURM/AD) for more information.

# Freescale Semiconductor, Inc.

Channel Number	Base Address	Parameter Address							
		0	1	2	3	4	5	6	7
0	\$YFFF##	00	02	04	06	08	0A	—	—
1	\$YFFF##	10	12	14	16	18	1A	—	—
2	\$YFFF##	20	22	24	26	28	2A	—	—
3	\$YFFF##	30	32	34	36	38	3A	—	—
4	\$YFFF##	40	42	44	46	48	4A	—	—
5	\$YFFF##	50	52	54	56	58	5A	—	—
6	\$YFFF##	60	62	64	66	68	6A	—	—
7	\$YFFF##	70	72	74	76	78	7A	—	—
8	\$YFFF##	80	82	84	86	88	8A	—	—
9	\$YFFF##	90	92	94	96	98	9A	—	—
10	\$YFFF##	A0	A2	A4	A6	A8	AA	—	—
11	\$YFFF##	B0	B2	B4	B6	B8	BA	—	—
12	\$YFFF##	C0	C2	C4	C6	C8	CA	—	—
13	\$YFFF##	D0	D2	D4	D6	D8	DA	—	—
14	\$YFFF##	E0	E2	E4	E6	E8	EA	EC	EE
15	\$YFFF##	F0	F2	F4	F6	F8	FA	FC	FE

— = Not Implemented (reads as \$00)

**Figure 1 TPU Channel Parameter RAM CPU Address Map**



W = Channel Number

Parameter Write Access

	Written by CPU
	Written by TPU
	Written by CPU and TPU
	Unused parameters

**Figure 2 UART Function Parameter RAM Assignment**

#### 4.1 RECEIVE\_DATA\_REG and TRANSMIT\_DATA\_REG

RECEIVE\_DATA\_REG holds data that has been received. The parameter word also contains the parity error (PE) flag and the framing error (FE) flag. Although the parameter RAM address of RECEIVE\_DATA\_REG can be read or written by the CPU, RECEIVE\_DATA\_REG should be treated as a read-only register. TRANSMIT\_DATA\_REG holds data that is to be sent. The parameter word also contains the transmit data register empty (TDRE) status bit.

#### 4.2 TDRE

This bit is set by the TPU to indicate that TRANSMIT\_DATA\_REG is empty. The function checks TDRE status every bit time while the transmitter is idle to determine whether there is new data to be transmitted in the register. TDRE must be cleared during or after each write — it is best to write each new value to TRANSMIT\_DATA\_REG with the MSB cleared. The state of the TDRE bit is duplicated in the channel interrupt status register. Either the TDRE or the interrupt status bit can be used to determine whether the transmitter is ready for new data. The interrupt status bit is best used in a polling environment, because using it reduces the likelihood of a RAM collision caused by the TPU and CPU attempting to read TRANSMIT\_DATA\_REG at the same time. If the interrupt status bit is used, clear it before each write to the data register. In any case, make certain that the TDRE is cleared before new data is written.

## 4.3 PE and FE

These bits are set or cleared by the TPU after each data word is received. Although the parameter RAM address of the receive data register can be read or written by the CPU, do not change the state of these bits during operation. When parity checking is enabled, PE is set if a parity error occurs during reception. It remains cleared otherwise. A framing error occurs when the function determines that a stop bit is low instead of high. FE is set when a framing error is detected. It remains cleared otherwise. Both the PE and FE bits are valid only while the erroneous data is in RECEIVE\_DATA\_REG.

## 4.4 Receive Data Indicator

The TPU sets the interrupt status bit in the interrupt status register after writing a data word into the RECEIVE\_DATA\_REG. The interrupt status bit must be cleared by the CPU immediately before or after reading the data register. In order to assure proper operation of the receiver, the entire parameter word, including RECEIVE\_DATA\_REG, PE, and FE state should be read at the same time.

## 4.5 MATCH\_RATE

This parameter specifies serial transmission baud rate. MATCH\_RATE is defined as TCR1 increments per bit time. MATCH\_RATE must be written before the function is started by the INIT host service request. It can be calculated using the formula:

$$\text{MATCH\_RATE} = \frac{\text{TCR1\_Clock}}{\text{Baud Rate}}$$

This is the same as system clock frequency + TCR1 prescaler rate ÷ baud rate. MATCH\_RATE must not be changed after function initialization.

## 4.6 DATA\_SIZE

This parameter specifies the number of bits to be sent out or received in one data word. The parameter commonly has a value of eight, because most serial protocols use 8-bit words.

## 4.7 PARITY\_TEMP

This parameter is written by a counter that counts the high bits in a word. The least significant bit of the parameter is used to generate parity. The parameter is used only by the UART function — the CPU must not change this parameter value while the function is running.

## 4.8 ACTUAL\_BIT\_COUNT

This parameter is written by a counter that counts bits shifted out of SHIFT\_REGISTER. The parameter is used only by the UART function — the CPU must not change this parameter value while the function is running.

## 4.9 SHIFT\_REGISTER

This parameter is used to shift data in or out. For a transmitter, data stored in TRANSMIT\_DATA\_REG is copied into SHIFT\_REGISTER when the TDRE bit is set, then shifted out onto the serial line. For a receiver, data is shifted into SHIFT\_REGISTER from the serial line until a word is complete, then copied into RECEIVE\_DATA\_REG.

## 5 Host Interface to Function

This section provides information concerning the TPU host interface to the function. **Figure 3** is a TPU address map. TPU register diagrams follow the figure. In the diagrams, Y = M111, where M is the value of the module mapping bit (MM) in the system integration module configuration register (Y = \$7 or \$F).

Address	15	8	7	0
\$YFFE00	TPU MODULE CONFIGURATION REGISTER (TPUMCR)			
\$YFFE02	TEST CONFIGURATION REGISTER (TCR)			
\$YFFE04	DEVELOPMENT SUPPORT CONTROL REGISTER (DSCR)			
\$YFFE06	DEVELOPMENT SUPPORT STATUS REGISTER (DSSR)			
\$YFFE08	TPU INTERRUPT CONFIGURATION REGISTER (TICR)			
\$YFFE0A	CHANNEL INTERRUPT ENABLE REGISTER (CIER)			
\$YFFE0C	CHANNEL FUNCTION SELECTION REGISTER 0 (CFSR0)			
\$YFFE0E	CHANNEL FUNCTION SELECTION REGISTER 1 (CFSR1)			
\$YFFE10	CHANNEL FUNCTION SELECTION REGISTER 2 (CFSR2)			
\$YFFE12	CHANNEL FUNCTION SELECTION REGISTER 3 (CFSR3)			
\$YFFE14	HOST SEQUENCE REGISTER 0 (HSQR0)			
\$YFFE16	HOST SEQUENCE REGISTER 1 (HSQR1)			
\$YFFE18	HOST SERVICE REQUEST REGISTER 0 (HSRR0)			
\$YFFE1A	HOST SERVICE REQUEST REGISTER 1 (HSRR1)			
\$YFFE1C	CHANNEL PRIORITY REGISTER 0 (CPR0)			
\$YFFE1E	CHANNEL PRIORITY REGISTER 1 (CPR1)			
\$YFFE20	CHANNEL INTERRUPT STATUS REGISTER (CISR)			
\$YFFE22	LINK REGISTER (LR)			
\$YFFE24	SERVICE GRANT LATCH REGISTER (SGLR)			
\$YFFE26	DECODED CHANNEL NUMBER REGISTER (DCNR)			

**Figure 3 TPU Address Map**

### CIER — Channel Interrupt Enable Register

**\$YFFE0A**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CH 15	CH 14	CH 13	CH 12	CH 11	CH 10	CH 9	CH 8	CH 7	CH 6	CH 5	CH 4	CH 3	CH 2	CH 1	CH 0

CH	Interrupt Enable
0	No interrupts
1	Interrupts enabled

### CFSR[0:3] — Channel Function Select Registers

**\$YFFE0C – \$YFFE12**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CFS (CH 15, 11, 7, 3)				CFS (CH 14, 10, 6, 2)				CFS (CH 13, 9, 5, 1)				CFS (CH 12, 8, 4, 0)			

CFS[4:0] — Function Number (Assigned during microcode assembly)

## HSQR[0:1] — Host Sequence Registers

**\$YFFE14 – \$YFFE16**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CH 15, 7	CH 14, 6	CH 13, 5	CH 12, 4	CH 11, 3	CH 10, 2	CH 9, 1	CH 8, 0								

CH	Operating Mode
00	No Parity
01	No Parity
10	Even Parity
11	Odd Parity

## HSRR[1:0] — Host Service Request Registers

**\$YFFE18 – \$YFFE1A**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CH 15, 7	CH 14, 6	CH 13, 5	CH 12, 4	CH 11, 3	CH 10, 2	CH 9, 1	CH 8, 0								

CH	Initialization
00	Not Used
01	Not Used
10	Transmit
11	Receive

## CPR[1:0] — Channel Priority Registers

**\$YFFE1C – \$YFFE1E**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CH 15, 7	CH 14, 6	CH 13, 5	CH 12, 4	CH 11, 3	CH 10, 2	CH 9, 1	CH 8, 0								

CH	Channel Priority
00	Off
01	Low
10	Middle
11	High

## CISR — Channel Interrupt Status Register

**\$YFFE20**

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
CH 15	CH 14	CH 13	CH 12	CH 11	CH 10	CH 9	CH 8	CH 7	CH 6	CH 5	CH 4	CH 3	CH 2	CH 1	CH 0

CH	Interrupt Status
0	No Interrupt
1	Interrupt Request

## 6 Function Configuration

### 6.1 Transmitter Initialization

Set parameters:

Write the desired baud rate value to MATCH\_RATE.

Write \$8000 to TRANSMIT\_DATA\_REG, to set TDRE. TDRE is not initialized by the host service request.

Write the number of bits per data word to DATA\_SIZE. This number represents only the number of data bits, and does not include start and stop bits or the parity bit.

Write the channel function select field. This value depends on the actual TPU code.

Set the host sequence bits to select the desired parity.

Clear any pending interrupt.

Set interrupt enable if required.

Issue host service request by writing %11 to the host service request field.

Write channel priority to start the function.

When initialization is complete, the interrupt status bit is set to indicate that TRANSMIT\_DATA\_REG is empty.

### 6.2 Transmitting Data

Wait for TDRE or interrupt status bit to be set, indicating that TRANSMIT\_DATA\_REG is empty.

Clear the MSB of the data word.

If using the interrupt status bit, clear it before writing TRANSMIT\_DATA\_REG.

Write the data word to TRANSMIT\_DATA\_REG.

### 6.3 Receiver Initialization

Set parameters:

Write the desired baud rate value to MATCH\_RATE.

Write the number of bits per data word to DATA\_SIZE. This number represents only the number of data bits, and does not include start and stop bits or the parity bit.

Write the channel function select field. This value depends on the actual TPU code.

Set the host sequence bits to select the desired parity.

Clear any pending interrupt.

Set interrupt enable if required.

Issue host service request by writing %10 to the host service request field.

Write channel priority to start the function.

### 6.4 Receiving Data

Wait for interrupt status bit to be set, indicating that RECEIVE\_DATA\_REG is full.

Read RECEIVE\_DATA\_REG.

Clear the interrupt status bit.

Check PE and FE bit status, using value read from the parameter. Do not read the parameter again for error testing.

## 7 Performance and Use of Function

### 7.1 Performance

Like all TPU functions, the performance limit of the UART function in a given application depends on the service time (latency) of other active TPU channels. This is due to the operational nature of the scheduler. To calculate the maximum performance of the function the user must know the execution time for the different states of the functions running at the same time. In general, the maximum service latency for every mode of the UART function must be less than one bit time, which depends on the baud rate. The function must be allowed this amount of time by the other running functions. For example, at 9600 baud the maximum latency of the UART function must be less than 104  $\mu$ s.



## Table 1 UART Function State Timing

State Number and Name	Max. CPU Clock Cycles	RAM Accesses by TPU
S1 Init_Receiver	4	0
S2 Init_Transmitter	4	1
S3 Polling_TDRE (Transmitter only) TDRE = 1 TDRE = 0	16 22	7
S4 Sending_Data (Transmitter only) Transmit stop bit with parity Transmit stop bit, no parity Transmit parity Transmit one data bit	12 20 32 28	8
S5 Receiving_Start_Bit (Receiver only) No parity selected Parity selected	16 18	2
S6 Receiving_Data_Bit (Receiver only) Receive stop bit Receive one data bit	44 + (2 * (16 – DATA_SIZE)) 20	8

NOTE: Execution times do not include the time slot transition time (TST = 10 or 14 CPU clocks)

### 7.1.1 Latency Examples

All examples assume that only the UART function is running. Examples are for absolute worst case, e.g. all receivers receive a stop bit at the same time, since this is the longest state.

When only transmitters are running, maximum baud rate for all channels combined is 360 kbaud. This can be one transmitter with 360 kbaud, or nine with 38.4 kbaud, or any other combination.

When only receivers are running, maximum baud rate is 233 kbaud. This can be one receiver with 233 kbaud, or six with 38.4 kbaud, or any other combination.

When both receivers and transmitters are running, maximum baud rate is 142 kbaud. This can be one pair running at 142 kbaud, or three pair at 38.4 kbaud, or seven pair at 19.2 kbaud, or any other combination.

### 7.2 Differences from a Conventional UART

The UART function does not implement MODEM control signals like RTS, CTS, and CD.

The receiver does not provide an overrun bit that is set when a received data word is not read by the CPU before a new data word arrives.

The transmitter does not provide an underrun bit.

The status bits are not cleared automatically by reading or writing the data registers.

The number of stop bits is fixed to one.

### 7.3 Limitations

To minimize TPU loading, the receiver does single sampling only. Each bit is sampled only once in the middle of the bit time — any glitch on the receive data line may cause erroneous data. The receiver does not detect idle line or break conditions, nor does the transmitter generate a break character.

Status bits must be handled by the CPU. These bits are set automatically by the TPU, but cannot be cleared by the function. The bits must be cleared by the CPU. This may cause a problem when the interrupt status bit is used to indicate that data has been received.

The interrupt status bit must be cleared by the CPU immediately before and after a read. The problem arises if the UART function receives new data before both actions are complete.

If the status bit is cleared immediately before reading data, a new data word might arrive before the previous data is read. In this case, the new word would be read, then the status bit would be set again, causing the word to be read a second time.

If the status bit is cleared immediately after data is read, a new data word might arrive before the status bit is cleared. In this case, the new data is not read, because the interrupt status bit is not set again.

To avoid these problems, the read routine must respond to the interrupt status bit quickly. The routine must execute completely before the function copies the received value from SHIFT\_REGISTER to RECEIVE\_DATA\_REG. For a 9600 baud receiver, the time to receive an 8-bit data word without parity is about 1 ms. The read routine must respond to the interrupt status bit within this time.

## 8 Examples

### 8.1 Example A: Implementing a Receiver

#### 8.1.1 Description

This example shows how to set up the UART function as a receiver, and how to service the incoming data. The user must decide how to handle parity and framing errors.

#### 8.1.2 Initialization

Sets up channel 0 as a receiver, with an 8-bit data word and no parity, using the variable BAUD to determine baud rate. BAUD value is a function of baud rate, IMB clock frequency, and TPU prescaler setting. The actual Baud rate is 9600. Received data is stored in RAM at addresses starting at \$6000. The value of the FUNCNUM variable is assigned during microcode assembly.

#### 8.1.3 Listing

```

FUNCNUM      EQU      $000B                ;Function Number for UART
BAUD          EQU      $01B2                ;9600 Baud Rate
MATCH_RATE    EQU      $FFFF02             ;Parameter RAM
RECEIVE_DATA  EQU      $FFFF04             ;Parameter RAM
DATA_SIZE     EQU      $FFFF06             ;Parameter RAM
TPUMCR        EQU      $FFFE00             ;TPU MODULE CONFIGURATION REGISTER
TICR          EQU      $FFFE08             ;TPU INTERRUPT CONFIGURATION REGISTER
CIER          EQU      $FFFE0A             ;CHANNEL INTERRUPT ENABLE REGISTER
CFSR3         EQU      $FFFE12             ;CHANNEL FUNCTION SELECT REGISTER 3
HSQR1         EQU      $FFFE16             ;HOST SEQUENCE REGISTER 1
HSRR1         EQU      $FFFE1A             ;HOST SERVICE REQUEST REGISTER 1
CPR0          EQU      $FFFE1C             ;CHANNEL PRIORITY REGISTER 0
CPR1          EQU      $FFFE1E             ;CHANNEL PRIORITY REGISTER 1
CISR          EQU      $FFFE20             ;CHANNEL INTERRUPT STATUS REGISTER

                ORG      $0                  ;Initialize the Reset Vectors

```

# Freescale Semiconductor, Inc.

```

DW      $0000                                ;Set Stack Pointer at 3FFC
DW      $3FFC
DW      $0000                                ;Set IP at $3000
DW      $3000

INCLUDE 'ORG00008.ASM'
*
* This file initializes the interrupt and exception
* vectors ($00008 - $001FF). If an unplanned
* interrupt occurs, program flow will continue at
* the label "BDM" which must exist in the user's
* main program. This label should have a "BGND"
* instruction to return control back to the monitor.

ORG      $3000                                ;Start Program at $3000
INITSYS:
ORI.W    #$2700,SR                            ;ensure supervisor mode, interrupts masked
MOVE.L   #$00000,D0
MOVEC    D0,VBR                                ;place VBR at $00000
MOVEA.L  #$FFF000,A0                          ;set A0 to point to start of SIM registers
MOVE.W   D0,($A20,A0)                          ;turn COP (software watchdog) off
MOVEQ    #$7F,D0                               ;w=0, x=1, y=111111
MOVE.B   D0,($A04,A0)                          ;system clock = 16.78MHz
LEA.L    $3FFC,A7                              ;Initialize Stack Pointer at $3FFC
LEA      $6000,A0                              ;Initialize A0 to Address $6000

***** Initialize TPU Register and Parameter RAM *****
INITIALIZE:
CLR.L    (CPR0).L                            ;Ensure Priority Bits are Cleared to 0
MOVE.L   #INT_SERVICE,($0100).L               ;Address of Interrupt Routine
MOVE.W   #$04CF,(TPUMCR).L                    ;TCR1 = Divide by 1, Int ARB ID = $F
                                                ;Prescaler Clock = Divide by 4
MOVE.W   #$0540,(TICR).L                      ;Interrupt Level = 5, Vector Number = $40
MOVE.W   #BAUD,(MATCH_RATE).L                 ;Set 9600 Baud Rate
MOVE.W   #$0000,(RECEIVE_DATA).L              ;Clear Receiver and Receive Flags
MOVE.W   #$0008,(DATA_SIZE).L                 ;Set Data Size
ANDI.W   #$FFFE,(CISR).L                      ;Clear Channel 0 Interrupt Flags
MOVE.W   #$0001,(CIER).L                     ;Enable Channel 0 Interrupts
MOVE.W   #FUNCNUM,(CFSR3).L                   ;Set Channel 0 to UART function
MOVE.W   #$0000,(HSQR1).L                    ;Select No Parity
MOVE.W   #$0002,(HSRR1).L                    ;Host Service Request Code for Receive
MOVE.W   #$0003,(CPR1).L                     ;Select High Priority
ANDI.W   #$FOFF,SR                            ;Set Interrupt Priority Mask Level to 0

***** Main Program *****
MAIN:
BRA      MAIN                                ;branch back to main

***** Interrupts/Exceptions *****
INT_SERVICE:
ANDI.W   #$FFFE,(CISR).L                    ;Clear Channel 0 Interrupt Flags
MOVE.W   (RECEIVE_DATA).L,D0                 ;Move Received Data to D0
ANDI.W   #$00FF,D0                           ;Data Register 0 has Received Byte
MOVE.B   D0,(A0)+
RTE

BDM:
BGND                                          ;exception vectors point here
                                              ;and put the user in background debug mode

```

## 8.2 Example B: Implementing a Transmitter

### 8.2.1 Description

This example shows how to set up the UART function as a transmitter, and how to service the transmit buffer.

### 8.2.2 Initialization

Sets up channel 1 as a transmitter, with an 8-bit data word and no parity, using the variable BAUD to determine baud rate. BAUD value is a function of baud rate, IMB clock frequency, and TPU prescaler setting. The actual Baud rate is 9600 using 4.1 MHz TCR1\_Clock. The value of the FUNCNUM variable is assigned during microcode assembly.

### 8.2.3 Listing

```

FUNCNUM      EQU      $00B0                ;Function Number for UART
BAUD          EQU      $01B2                ;9600 Baud Rate
MATCH_RATE1   EQU      $FFFF12             ;Parameter RAM
TRANSMIT_DATA EQU      $FFFF14             ;Parameter RAM
DATA_SIZE1    EQU      $FFFF16             ;Parameter RAM
TPUMCR        EQU      $FFFE00             ;TPU MODULE CONFIGURATION REGISTER
TICR          EQU      $FFFE08             ;TPU INTERRUPT CONFIGURATION REGISTER
CIER          EQU      $FFFE0A             ;CHANNEL INTERRUPT ENABLE REGISTER
CFSR3         EQU      $FFFE12             ;CHANNEL FUNCTION SELECT REGISTER 3
HSQR1         EQU      $FFFE16             ;HOST SEQUENCE REGISTER 1
HSRR1         EQU      $FFFE1A             ;HOST SERVICE REQUEST REGISTER 1
CPR0          EQU      $FFFE1C             ;CHANNEL PRIORITY REGISTER 0
CPR1          EQU      $FFFE1E             ;CHANNEL PRIORITY REGISTER 1
CISR          EQU      $FFFE20             ;CHANNEL INTERRUPT STATUS REGISTER

                ORG      $0                  ;Initialize the Reset Vectors
                DW       $0000              ;Set Stack Pointer at 3FFC
                DW       $3FFC
                DW       $0000              ;Set IP at $3000
                DW       $3000

                INCLUDE 'ORG00008.ASM'
*          This file initializes the interrupt and exception
*          vectors ($00008 - $001FF). If an unplanned
*          interrupt occurs, program flow will continue at
*          the label "BDM" which must exist in the user's
*          main program. This label should have a "BGND"
*          instruction to return control back to the monitor.

                ORG      $3000              ;Start Program at $3000
INITSYS:

                ORI.W    #$2700,SR          ;ensure supervisor mode, interrupts masked
                MOVE.L   #$00000,D0
                MOVEC    D0,VBR             ;place VBR at $00000
                MOVEA.L  #$FFF000,A0       ;set A0 to point to start of SIM registers
                MOVE.W   D0,($A20,A0)      ;turn COP (software watchdog) off
                MOVEQ    #$7F,D0           ;w=0, x=1, y=111111
                MOVE.B   D0,($A04,A0)      ;system clock = 16.78MHz
                LEA.L    $3FFC,A7          ;Initialize Stack Pointer at $3FFC
                LEA      $6000,A0          ;Initialize A0 to Address $6000

***** Initialize TPU Register and Parameter RAM *****
INITIALIZE:
                CLR.L    (CPR0).L          ;Ensure Priority Bits are Cleared to 0

```

```

MOVE.W #$8000,(TRANSMIT_DATA).L    ;Set TDRE Bit
MOVE.W #BAUD,(MATCH_RATE1).L       ;Set 9600 Baud Rate for Transmitter
MOVE.W #$0008,(DATA_SIZE1).L       ;Set Data Size
MOVE.L #INT_TRANSMIT,($0104).L      ;Address of Transmitter Interrupt
                                   ;Routine

MOVE.W #$04CF,(TPUMCR).L;TCR1 = Divide by 1, Int ARB ID = $F
                                   ;Prescaler Clock = Divide by 4

MOVE.W #$0540,(TICR).L              ;Interrupt Level = 5, Vector Number = $40
ANDI.W #$FFFD,(CISR).L              ;Clear Channel 1 Interrupt Flag
MOVE.W #$0002,(CIER).L              ;Enable Channel 1 Interrupt
MOVE.W #FUNCNUM,(CFSR3).L           ;Set Channel 1 to UART function
MOVE.W #$0000,(HSQR1).L             ;Select No Parity
MOVE.W #$000C,(HSRR1).L             ;Host Service Request Code for Transmit
MOVE.W #$000C,(CPR1).L              ;Select High Priority
ANDI.W #$FOFF,SR                    ;Set Interrupt Priority Mask Level to 0
JSR    SEND_FIRST                    ;Send First Byte

***** Main Program *****
MAIN:
        BRA    MAIN                  ;branch back to main

***** Subroutine *****
SEND_FIRST:
        CLR.W  D0                    ;Send First Byte
        *                               ;Whenever the User Write the Data to
        *                               ;TRANSMIT_DATA_REGISTER, TDRE bit must
        *                               ;be Cleared.
        LEA    STRING,A1             ;A1 points to the beginning of ASCII
        MOVE.B (A1)+,D0               ;Get First Byte in String Pointed by A1
        MOVE.W D0,(TRANSMIT_DATA).L  ;Write the Data to Transmit Register
        RTS

***** Interrupts/Exceptions *****
INT_TRANSMIT:
        ANDI.W #$FFFD,(CISR).L       ;Clear Channel 1 Interrupt Flag
        CLR.W  D0                    ;Whenever the User Write the Data to
        *                               ;TRANSMIT_DATA_REGISTER, TDRE bit must
        *                               ;be Cleared.
        MOVE.B (A1)+,D0               ;Get Next Byte in String Pointed by A1
        BEQ    STRING_DONE            ;If Byte = 0, then End of String

TRANSMIT:
        MOVE.W D0,(TRANSMIT_DATA).L  ;Write the Data to Transmit Register
        RTE

STRING_DONE:
        JSR    SEND_FIRST             ;Reached the End of String
        RTE                            ;Send First Byte

BDM:
        BGND    ;exception vectors point here
                                   ;and put the user in background debug
                                   ;mode

ORG    $4000

STRING:
        DB      'Asynchronous Serial Interface TPU function',0A,0D,00

```

## 9 Function Algorithm

The following description is provided as a guide only, to aid understanding of the function. The exact sequence of operations in microcode may be different from that shown, in order to optimize speed and code size. TPU microcode source listings for all functions in the TPU function library can be downloaded from the Motorola Freeware bulletin board. Refer to *Using the TPU Function Library and TPU Emulation Mode* (TPUPN00/D) for detailed instructions on downloading and compiling microcode.

The UART function consists of six states, described below.

### 9.1 State 1: Init\_Receiver

This state is entered as a result of a host service request type %10. It configures the channel for input with TCR1 as timebase and 'detect falling edge' pin control. The channel is configured to wait for the falling edge of the start bit.

### 9.2 State 2: Init\_Transmitter

This state is entered as a result of a host service request type %11. It configures the channel for output with TCR1 as timebase, sets the pin to high (idle state) and defines 'no action' pin control. It sets up a match at (TCR1 + MATCH\_RATE) which causes entry to state 3 (Polling\_TDRE).

### 9.3 State 3: Polling\_TDRE (Transmitter only)

This state is entered as a result of a match. It checks the TDRE bit. A new match is scheduled at (Event time + MATCH\_RATE). If TDRE is not set, the 'no action' option is used, otherwise 'pin\_low' is selected to generate the start bit. In this case RECEIVE\_DATA\_REG is copied to the SHIFT\_REGISTER and TDRE is set. An internal flag is set to enter state 4 instead of state 3 next time.

### 9.4 State 4: Sending\_Data (Transmitter only)

This state is entered as a result of a match. A new match is scheduled at (Event time + MATCH\_RATE). The pin action is defined by the next bit to be sent out. After sending the stop bit, the internal flag is cleared, to enter state 3 instead of state 4 next time.

### 9.5 State 5: Receiving\_Start\_Bit (Receiver only)

This state waits for the falling edge of a start bit. It is entered as a result of a falling edge transition. A match is scheduled at (Event time + MATCH\_RATE \* 1.5) to be able to get the middle of the first bit. Also an internal flag is set to enter state 6 instead of state 5 next time.

### 9.6 State 6: Receiving\_Data\_Bit (Receiver only)

This state is entered as a result of a match. The pin state is shifted into SHIFT\_REGISTER. If this is not the last bit, then a new match is scheduled at (Event time + MATCH\_RATE), otherwise this bit (stop bit) is checked as well as the parity (if selected). The data is copied to RECEIVE\_DATA\_REG and an interrupt service request is made. The channel is again configured to wait for the next falling edge (next start bit). The internal flag is cleared again to enter state 5 instead of state 6 next time.



# Freescale Semiconductor, Inc.

Freescale Semiconductor, Inc.

Motorola reserves the right to make changes without further notice to any products herein. Motorola makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Motorola assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Motorola data sheets and/or specifications can and do vary in different applications. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Motorola does not convey any license under its patent rights nor the rights of others. Motorola products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Motorola product could create a situation where personal injury or death may occur. Should Buyer purchase or use Motorola products for any such unintended or unauthorized application, Buyer shall indemnify and hold Motorola and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Motorola was negligent regarding the design or manufacture of the part. MOTOROLA and ! are registered trademarks of Motorola, Inc. Motorola, Inc. is an Equal Opportunity/Affirmative Action Employer.

## How to reach us:

**USA/EUROPE/Locations Not Listed:** Motorola Literature Distribution;  
P.O. Box 5405, Denver Colorado 80217. 1-800-441-2447, (303) 675-2140

**JAPAN:** Nippon Motorola Ltd.; Tatsumi-SPD-JLDC,  
6F Seibu-Butsuryu-Center, 3-14-2 Tatsumi Koto-Ku, Tokyo 135, Japan. 81-3-3521-8315  
**ASIA PACIFIC:** Motorola Semiconductors H.K. Ltd.; 8B Tai Ping Industrial Park,  
51 Ting Kok Road, Tai Po, N.T., Hong Kong. 852-26629298



**MOTOROLA**

**For More Information On This Product,  
Go to: [www.freescale.com](http://www.freescale.com)**